

INSTALLATION INSTRUCTIONS

KRAIBURG Softbed LongLine



$\mathbf{2}$) Install first foam layer ("Purel")

Align multicolored, firmer "Purel" foam along the placement line 173 cm, allow space for the closure bars on the side edges (see step 6)



Tip for deep dividers: Use a wooden board as a limitation at the front edge to prevent the foam from slipping.









Align the second foam exactly on the lower foam panels, taking into account the placement line and space for the closure bars on the side edges (see step (6))

2

Wave-cut design upwards



Roll out and position rubber flooring



Always make sure the front


the line. Re-adjust, if


edge of the mat is located on

Fix


Start from the center of the roll and fix on the right and on the left. Recommendation: Work from the head space to prevent the components from slipping.

 (\mathbf{I})





Distance between the mat edge and the outermost fixings: Max. 12 cm!




necessary.


With a distance greater than 12 cm: Place an additional fixing point

Further about (5) Fix:

B Fix bars: See **6B**

KRAIBURG kraiburg-elastik.com





Optional: Connect two rolls with a middle bar (underneath a divider) Insert WS-M 170 middle bar Insert WS-M 170 middle bar Provide the series of t

DO NOT PRESS!



3